

# Optical Fiber Tester

USER'S MANUAL

## Warning

When using this instrument, please do not look directly at the optical interface or the end of the optical fiber with your eyes, avoid eye damage! Any change or modification not explicitly permitted in this manual will deprive you of the right to operate the equipment. To reduce the risk of fire or electric shock, do not expose the equipment to thunderstorm or humid environment. In order to prevent electric shock, do not open the shell, it must be repaired by the qualified personnel designated by the manufacturer.


## Attention

**Battery:** The battery in the machine is a special lithium-ion polymer battery. The charging voltage is 5V, and the charging temperature ranges from 0 C ~ 50 C. When the ambient temperature is too high, the charging will automatically terminate. When the instrument is not used for a long time, the battery should be removed. The temperature range of the battery during long-term storage is -20 C ~ 45 C.

Please use the special AC adapter attached to this instrument and use the external power supply strictly according to the specifications, otherwise the equipment may be damaged.

**LCD screen:** The display of this series of instruments is 3.5 inch color LCD. In order to maintain good viewing effect, please keep the LCD screen clean and clean. When cleaning, the LCD screen can be cleaned by wiping with soft fabric.

## Brief



### Top view

- ① OTDR/LS Port
- ② OPM Port
- ③ VFL Port
- ④ Flashlight

### Left side

- ① Micro USB
- ② Charging LED Indicator
- ③ TF Card Port

### Right side

- ① RJ45 Interface
- ② Reset button

### Bottom view

- ① RJ45 Remote tester

### Main view

- ① Dust Cover
- ② 3.5 inch Color LCD
- ③ Function Keys

## Functional Keys

Functional keys correspond to the operation menu below the screen.



### Zoom key

Zoom function key, combined with direction keys to operate.

### ON/OFF key

Short press to turn on, long press to turn off; after turning on, short press to turn on or off the flashlight.

### OK key

Enter the next level of interface, Enter function

### Measure key

Press to start or stop the test under the OTDR interface

### Exit key


Return to the previous menu

### Directional keys

Up and down choice, right and left choice


## Main Interface

Turn on and enter the main menu. There are eight functional modules. Select the module by pressing the direction keys, and then press the "OK" key to enter the corresponding functional interface.




## OTDR

- F1: Enter the parameter setting interface
- F2: Switching A/B cursor
- F3: Enter the save interface
- F4: File or Folder operation




## OTDR Setting Interface

**OTDR setting interface**  
Enter the parameter setting interface. Multi-digit settings, through the left and right key positioning cursor, up and down selection.  
▲▼: Choosing settings items.  
Press OK button to confirm or edit corresponding measurement parameters.




- F1: Test
- F2: OK
- F3: Recovery
- F4: Cancel



## Test Results


Link quality and information can be viewed from the top after the test is completed, link information includes length, total loss and number of events.  
Detailed event information can be viewed from the event list.

- There are Four types of events:
- Reflective event
  - Non-reflective event
  - Fiber splitter
  - Fiber end



## OTDR-Zoom mode

- Press to enter zoom mode
- X-axis direction zoom in
- X-axis direction zoom out
- Y-axis direction zoom in
- Y-axis direction zoom out
- Press 1:1 display



## OTDR-File Save


9.

### OTDR-File Save

Press **F3** (Save) key to save file after test complete, pop up the keyboard, enter the name of the file, and press Enter to save the file. If the automatic save (otdr) function is turned on in "System Settings", it will be saved automatically after the test complete without manual operation.

### Auto-save function

Enter the system settings, open the auto-saving function, the instrument will automatically save the test files after the average or auto-test.



## OTDR-File Operation

10.

### OTDR-File Operation

Press **F4** to enter the file list.

Press the **OK** key to open a folder or File.

F1: Open file

F2: Delete file

F3: Rename file

F4: Return to the main menu



## iLOM(Event Map)


11.

The function can be tested automatically by one key, and the information of the length of the link, the type of event point and the position of breakpoint can be displayed in a graphical form. The result is clear and easy to understand.



Press left and right buttons to switch events

Note: The function module is optional accessories.



## OPM

12.

This function is used to test the power of optical signal and insertion loss of various devices and optoelectronic components. It can identify and measure the frequency of 270/330/1k/2kHz frequency optical signal.

F1: Switching wavelength

F2: Setting Reference Power

F3: Zero Reference Power


F4: Enter the Calibration Mode

Absolute power, relative power and linear power are converted as follows:

$$P_{Abs.} = 10 \lg P_{Lin.} / 1mW$$

$$P_{Rel.} = P_{Abs.} - P_{Ref.}$$

Reference Power  
Absolute Power  
Power Measurement Range  
Relative Power  
Linear Power  
Frequency Measurement



## VFL

13.

Visible red light (650 nm) is injected into the optical fiber, and the position of the optical fiber fault point can be judged conveniently and accurately by observing the leakage position on the measured fiber. It is suitable for the detection of bare optical fibers, jumpers and other high loss sections caused by near-end faults and micro-bending of optical fibers and cables which can leak red light.

Avoid looking directly at the laser output port.

Laser can cause damage to human retina.

F1: Open VFL

F2: VFL flash at 1 Hz

F3: VFL flash at 2 Hz

F4: Turn off VFL

Status Indicator

Warning information



## LS-Laser Source

14.

The wavelength of stabilized laser source is the same as OTDR wavelength. It is used to measure the parameters of telecommunication, CATV, LAN cable, insertion loss, isolation loss and echo loss of optical passive devices, and wavelength responsiveness of detectors.

There are five modes of light source: CW, 270 Hz, 330 Hz, 1 kHz and 2 kHz.

F1: Open LS

F2: Turn off LS


F3: Switch LS Wavelength

F4: Switch LS Mode

LS Information

Mode

Warning Information



## RJ45 Sequence

15.

RJ45 line sequence measurement.

F1: Start Test

F3: Switch Line Sequence Test Standard

F4: Return to the main menu

Test Standard

Test Results

Tips




## RJ45 Line Length & LineTracker

16.

### RJ45 Line Tracker

Used for RJ45 cable length testing and wire tracker. After the line-finding function is activated, the cable being searched is touched by the distal end of the line-searching, and the sound of continuous "drops and drops" is heard.



### RJ45 Line Length Test

F1: Start Line Length Test

F2: Switch Line Length Unit

F3: Switch Line Sequence Test Standard

F4: Start Line-tracker Function

Note: The function module is optional accessories.

Test Standard

Test Results

Tips



## System settings

17.

Set up automatic shutdown, backlight brightness, time, language, upgrade and other information.

F1: Optional for switching the current menu

F3: System Software Upgrade

F4: Confirmation settings



Switch settings entry ▲▼

Switch options of current entry ►◀

